

<b>ARCS PROCEDURE:</b>	<b>STARTING THE ISS</b>	<b>PRO(ISS)-005.000</b>
<b>Author: P. Johnston</b>		<b>April 13, 1999</b> <b>Page 1 of 1</b>

## Starting the ISS

### I. Purpose:

This document contains the basic startup procedure for the Nauru NOAA ISS. This is a small Doppler radar that measures the winds above the station. It also has a small automatic surface meteorological station.

### II. Cautions and Hazards:

- None.

### III. Requirements:

- None.

### IV. Procedure:

#### A. Steps:

1. Turn on both UPS units.
2. Make sure the JAZ drives are turned on. The switch is on the left rear of the JAZ drive.
3. Turn on the two video monitors.
4. Turn on the NAURUCOMM computer.
5. Turn on the NAURU915 computer.
6. The ISS system will start operating automatically.

### V. References:

None.

### VI. Attachments:

None.