

ARCS PROCEDURE: Author: P. Malone	TURNING ON/OFF THE INMARSAT-B UNIT	PRO(OPS)-019.000 May 12, 1999 Page 1 of 2
--	---------------------------------------	---

Turning ON/OFF the INMARSAT-B Unit

I. Purpose:

To describe the procedure for turning ON/OFF the INMARSAT-B unit in Manus.

II. Cautions and Hazards:

None.

III. Requirements:

None.

IV. Procedure:

A. Location:

1. The INMARSAT-B unit is located in a black box on the floor under the MACS computer in the D-Van.

B. To turn the unit ON:

1. There are two (2) power cords coming out of the black box on the floor under the MACS computer. Plug both of the power cords into the orange electrical sockets located behind the black box. This will power up the INMARSAT-B unit and the router needed to connect with PNNL.

C. To turn the unit OFF:

1. There are two (2) power cords coming out of the black box on the floor under the MACS computer. Unplug both of the power cords from the orange electrical sockets located behind the black box. This will turn off the INMARSAT-B unit and the router.

V. References:

None.

VI. Attachments:

1. INMARSAT-B Logging Form